


Password

To change the password of the currently logged in user, enter the old password, enter the new password twice and then click **Apply** to save the changes.



The image shows a window titled "Password" with standard window controls (minimize, maximize, close) in the top right corner. Inside the window, there is a form with four input fields: "Username" (containing the text "admin"), "Old Password", "Password", and "Confirm". Below these fields is a button labeled "Apply".

From:
<http://wiki.myakitio.com/> - **MyAkitio Wiki**

Permanent link:
http://wiki.myakitio.com/applications_password

Last update: **2012/12/20 14:03**

